

## RS DigiTac

### Digital Tachograph Software



### Installation and Registration Manual

Thank you for choosing the RoadSoft products. Now, over 10.000 companies are using our solutions. Thanks to the feedback from our customers, our products are what they are today, very user-friendly. Please feel free to give us your feedback on our products, in order to improve them and strive for excellence!

Our customer satisfaction resulted in word of mouth recommendation. We value recommendations from truck operators to their 'colleagues' very much, we hope you will also recommend us, when you are satisfied.

## Introduction

---

RS DigiTac is the software for downloading and analyzing digital tachograph data. With RS DigiTac you can view the activities of your drivers and vehicles, analyze data and create reports. You are also able to export and print data if needed, in different easy-to-read formats. Your data is also saved in its original format, as required by the European Law Regulation.

RS DigiTac can operate with Windows 2000, XP, Vista, 7.

## NOTE



This manual will guide you step by step in installing and registering the software. Please take your time to read it; it prevents you from making mistakes. Once you have read this manual, you will see that the software is very easy to use.

## Installing RS DigiTac Software


---

Insert the CD in your PC → “Computer Resources” → click on “Digitac” → click on “setup.exe”.


You’ll see the following screens:



Click on “OK”.




Click on the “Computer icon” and make a selection, as next:




Click on **“Continue”**.


You will see:




Wait for the setup to be complete and you'll see the following screen:




Click on **“Next”**.




Click on "Install".



Wait for the setup to be complete and then you'll see a window, as the following one:




Click on **“Finish”**.




The installation is successful!

Now click on **“Start”** → **“Programs”** → **“Digitac”**.




A window like the next one will appear:




To continue with the process, click the “**Next**” button.

A window like the one below presents you the license agreement.




After you find out about the terms of the license, you can continue.

In order to do this, select the option “I accept the terms of the license agreement” and click “Next”.




The next window you see will be like this one:




Again, click on the “Next” button.

In the new window, click the “Install” button.




This way, the installation of the RS DigiTac software will continue.



The previous window shows the process of the installation, basically its evolution.

The window you see next will appear when the process of installation for the RS DigiTac software on your PC will be complete.



Click on **“Finish”** to finalize the process.


## Registering RS DigiTac Software

---

RS DigiTac comes with a full 14 day trial license, during which time the software is fully operational.

Once RS DigiTac is installed, you also need to register the license for your PC. You will need the serial number information provided on either the back cover of your CD case or provided to you directly when the software was purchased. You can then use one of three methods for requesting a license key: Online, Email, Fax.

The first time you run RS DigiTac, it will display the license screen:



Step 1 - Registratgion Information

Please enter the Serial ID that came with your software, along with a valid e-mail address.

Serial ID : TRKS-EEQV-WMwW (XXXX-XXXX-XXXX)

Email :

Step 2 - Licence request options

Please choose a method of registration and click "Request". Your licence key will normally be returned to you within 24 hours upon receipt

Online  Email  Fax

Licence Information

Hardware ID : 4FF1715A-55DB546A-3EF5B18E-3ABFD84B

Licence Key : D5D98CA6-90AAF1F1-42BE702B-6B0D623C-0B053CF0

You will need to fill in the **“Serial ID:”** and the **“Email:”** fields on the screen. Then simply choose your method of requesting your license and press the **“Request”** button (that now should be active), in the right side.

### Online

- if you choose the “**Online**” registration process, you will need to be connected to the internet;
- the program will automatically allocate a license key for you within 24 hours (Monday to Friday);
- you will not receive a notification of registration.

### Email

- if you choose the “**Email**” registration process, you will also need to be connected to the internet;
- RS DigiTac will then generate an email for you to send, requesting a full license;
- a full license will be automatically returned to you within 24 hours (Monday to Friday), license key which will need to be entered in the licensing screen;
- in order to do this, from the main menu click on “**Help**” → “**Register**” → enter the license key that has been issued to you → click “**Validate License Key**” and this is it;
- in the “**Registration**” screen you saw that there was already a license key stated, but it is just a temporary one.

### Fax

- when choosing the “**Fax**” registration process, you don’t need to be connected to the internet;
- RS DigiTac will generate a fax for you to send, requesting a full license;
- a full license will be automatically returned to you within 24 hours (Monday to Friday), license key which will need to be entered in the licensing screen;
- in order to do this, from the main menu click on “**Help**” → “**Register**” → enter the license key that has been issued to you → click “**Validate License Key**” and this is it;
- in the “**Registration**” screen you saw that there was already a license key stated, but it is just a temporary one.

**Thank you for choosing the RoadSoft products!**